





preparation



- ȳ Mixing Place
water in a clean container and add dry mortar.
Mix intensively and homogeneously for approx. 3 minutes using a suitable mixing tool.

processing



- ȳ Processing conditions material,
ambient and substrate temperature: min. +5 °C to max. +30 °C.
Low temperatures lengthen, high temperatures shorten the processing and hardening time.

- ȳ Processing time (+20 °C)
Approx. 60 Minutes

Contact layer
Apply product as a contact layer using a suitable tool.

Apply surface design
material approx. 2 mm.
Smooth the surface with a suitable tool.
Post-processing of the surface after stiffening.
Can be sanded after hardening.

Processing instructions

Work fresh on fresh, avoid approaches.
Stiffened mortar must not be made workable again with either water or fresh mortar.
Depending on the environmental conditions, if the interior is heated or there is a draft, protect it from drying out too quickly with foil or similar.
Hairline cracks/shrinkage cracks are harmless and should not be criticized as they do not affect the properties.

Hints

The functionality against mold infestation and condensation is only possible in conjunction with mold renovation plaster and SLP CS panels.

Product characteristics were determined under laboratory conditions at 20 °C and 65% relative humidity.
Do not work on damp surfaces.

The color that appears after drying and hardening depends on the ambient conditions and the processing method. A freshly smoothed surface appears brighter compared to a late smoothed or roughened surface. Different grain sizes of the same item can lead to slight variations in color. Subsurfaces that are damp from the back can cause discoloration.

Do not use on surfaces containing gypsum!
Mixing water must be of drinking water quality.
Low in chromate according to RL 2003/53/EC.
Always create test area(s)!
Deviations from current regulations must be agreed upon separately.
The existing test certificates must be observed during planning and execution.

Work equipment/cleaning



Mixing tool, trowel, smoothing trowel, sponge board, float Clean tools
with water when they are fresh.

Remmer's tools
ȳ [Mixing vessel \(4030\)](#) ȳ
[Collomix® stirrer KR \(4292\)](#) ȳ
[HEXAFIX® retrofit adapter \(4283\)](#) ȳ
[Remmers Whisk \(4282\)](#) ȳ
[Masking paper \(5019\)](#) ȳ
[Smoothing trowels \(4004\)](#)
ȳ [Smoothing trowel \(4117\)](#) ȳ [Smoothing trowel duo \(4118\)](#) ȳ [Latex float \(4548\)](#)
ȳ [Sponge board yellow \(4936\)](#) ȳ
[Plastering and smoothing filler XXL Coating knife \(4437\)](#)

